

#### DB Since Sin

# for HOVIS Lite/Eco+/Genie

- DR–SIM Installation
- Hello DR-SIM
- DR-SIM User Interface
- Help
- DR—SIM Download
- Creating Motion

www.dongburobot.com

로봇실행 이번


# For Hovis Lite, Eco

#### DR-SIM for HOVIS Lite

01. Installation	06
02. Hello DR-SIM	09
03. User Interface	13
04. Help	14
05. Download	15
06. Creating Motion	27

# CONTENTS

◇ DR-SIM - demo⊥r,dmt 파일 보기 프레임 포즈	로봇 도	구 도음말	_	_	_	53	in <u>com</u> ) i	표조 캡쳐		·	_
	6 G X	ũ 0	PP	00	Ø			2	<u>경</u> 급기 로봇	মণ জ	경설
*				+							Ì
5 10 15	20 25	20	25 A	10 45	50 55	80	65 70	71			20
				•						,.,.	,.
							0.0.0				
30 모션 휜도우	_	Frami	e : 210	영광 LED	서보 모	터값	-	-	-	-	
30 모션 원도부	_	_		영글 LED Index : 0		터값 Motor ID	Value	LED	Motor ID	Value	
30 모션 원도우	-	0	ി			Motor ID	Value 44		Motor ID	Value	
90 52 d 85 f		C a			LED	Motor ID					
30 24 857		C a	ូ	Index : O	LED	Motor ID	44		<b>∨</b> 10	0	
30 52 8 25 <del>7</del>		0	े 2	Index : O	LED	Motor ID	44	RGE RGE RGE	<ul><li>✓ 10</li><li>✓ 11</li></ul>	0	
30 528 25 #	5	0 2 8 9 0	े 2	Index : O	LED	Motor ID v 0 v 1 v 2	44 80 0	100 100 100 100 100 100	<ul><li>✓ 10</li><li>✓ 11</li><li>✓ 12</li></ul>	0	
30 24 25 ¥		0 2 8 9 0	ି ୬ <b>ପ କ</b> ୁ ନ	Index : O	LED	Motor ID 0 1 2 3	44 80 0 -90		<ul> <li>10</li> <li>11</li> <li>12</li> <li>13</li> </ul>	0 0 0 0	
30 94 #57		<mark>)</mark> 2 2 2 4 2 3 4	ି ର <b>ପ କ</b> ନି କ	Index : 0 선택/편집 발산음		Motor ID V 0 V 1 V 2 V 3 V 4	44 80 -90 77		<ul> <li>10</li> <li>11</li> <li>12</li> <li>13</li> <li>14</li> </ul>	0 0 0 0 0 0	
20 22 2 22		<mark>)</mark> 2 2 2 4 2 3 4	ି ର <b>ପ କ</b> ନି କ	index : 0 선택/편집 발전음		Motor ID V 0 V 1 V 2 V 3 V 4 V 5 V 6	44 80 -90 77 0		<ul> <li>✓ 10</li> <li>✓ 11</li> <li>✓ 12</li> <li>✓ 13</li> <li>✓ 14</li> <li>✓ 15</li> <li>✓ 16</li> </ul>	0 0 0 0 0 0 0 0 0	



# Installation

#### **DR-SIM Introduction**

DR-SIM, also called 'motion editor' is an easy to use robot motion editing software tool. In addition to motion creation, editing, and capturing actual robot motion, DR-SIM supports powerful simulation function that allows the user to simulate the motion prior to applying it to the robot. DR-SIM also incorporates timeline feature similar to the ones found in video editing software.

Timeline allows the user to create motion based on time and to add multimedia effect to the motion by adding LED lighting effect and sound in the timeline.

- System requirement
- Minimum Intel Pentium 800 Mhz
- Windows XP, Windows Vista, Windows 7
- Minimum 256 MB RAM
- Hard Disk Space 300 MB required
- USB Port
- Macintosh(under development)

#### Follow Instructions / From installation to running the program



#### 01 Installation File


Click on installation file.

🖟 DR-SIM	02 Start installation wizard
Welcome to the DR-SIM Setup Wizard	Click "Next" button.
The installer will guide you through the steps required to install DR-SIM on your computer.	
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the tau.	
Cancel < Back Next >	


🖟 DR-SIM
Select Installation Folder
The installer will install DR-SIM to the following folder.
To install in this folder, click "Next". To install to a different folder, enter it below or click "Browse".
Eolder: E:\Program Files\Dongbu Robot\DR-SIM\ Disk Cost
Install DR-SIM for yourself, or for anyone who uses this computer:
<ul> <li>● Everyone</li> <li>○ Just me</li> </ul>
Cancel ( <u>B</u> ack Next)

#### 03 Select installation folder

Click "Next" button.



🛃 DR-SIM			
Installing DR-SIM			
DR-SIM is being installed.			
Please wait			
	Cancel	< <u>B</u> ack	Next >





#### 04 Confirm installation

Click "Next" button.

#### 05 Start installation

Starting installation. Wait untill the installation bar ends.

#### 06 Confirm installation

Click "Close" button Software installation complete.

#### 07 Check executable file

Check for the executable file, desktop shortcut icon and from Windows Start > All Programs > Dongbu Robot > DR-SIM. Click on the executable file to run the program.

If the porgram did not install properly, install the Microsoft, Net Frame work 3.5 and try again.


# Hello DR–SIM

First example of creating motion. Use DR-SIM tor create simple motion and run the motion simulation.

Connect to the robot and download the created motion file and then check the motion being applied by the robot.



le View Frame Pose Robot Tool	Help	Torque On Of Pose Castin Acoly Motion Play St
	1 P P 🛛 🖸 🖸	Connect Robot Control Setti
5 10 15 20 25	\$8 \$5 40 45 50	55 68 65 76 75 80 85
3 4 5 8 7 8 9 8 9 12 2 5 4 5 6 7 8 9 6 12 2 5 5 4	03102028-653007100504+4142424444548474349865152	an a
D Motion Window	Frame : 0 Face LED	Servo Motor Value
		LED Motor ID Value LED Motor ID Value
		LED MOTORID Value LED MOTORID Value
		LED MOLOFID Value
	© © <b>1</b> © <b>2</b> ● <b>Edit</b>	
	00	Image: Second
	© © <b>1</b> © <b>2</b> ● <b>Edit</b>	w         0         -90         0         9         0         9           w         1         90         0         0         0         0           w         1         90         0         0         10         0           w         2         0         0         0         0         11         0
	12 0 13 02 24 0 (2) 21 (2) 21 (2	V         0         -00         -00         V         9         0           V         1         00         0         V         10         0           V         2         0         0         V         10         0           V         2         0         0         V         11         0           V         3         -00         V         V         12         0           V         4         90         0         V         13         0           V         5         0         V         14         0
		W         0         -20         W         9         0           W         1         90         0         W         10         0           W         2         0         0         W         11         0           W         3         -00         0         W         12         0           W         3         -00         0         W         12         0           W         4         00         0         W         13         0           W         6         0         0         W         15         0
	1         0         Edit           1         0         Edit           1         0         0           1         0         0           1         0         0           1         0         0           1         0         0           1         0         0           1         0         0           1         0         0           1         0         0	V         0         -00         -00         V         9         0           V         1         00         0.0         V         100         0           V         1         00         0.0         V         100         0           V         2         0         0.0         V         110         0           V         3         -00         0.0         V         112         0           V         4         00         0.0         V         130         0           V         5         0         0.00         V         14         0
	1         1         Edit           1         1         Edit           1         1         1           1         1         1           1         1         1           1         1         1           1         1         1           1         1         1           1         1         1           1         1         1	W         0         -20         -20         W         9         0           W         1         90         0         0         0         0         0           W         2         0         0         0         0         0         0         0           W         2         0         0         0         0         11         0           W         3         -00         0         0         0         0         0           W         3         -00         0         0         0         0         0           W         4         00         0         0         0         0         0         0           W         5         0         0         0         0         14         0           W         6         0         0         0         15         0         0



#### 00 Run program

Click on DR-SIM icon and run the program.

#### O 1 Full Screen

DR-SIM Full Screen.

Timeline is in the middle and motion editior at botom.


Motion is usually created or edited using the timeline and 3D motion window.


#### 02 Basic Posture

Insert the basic posture in the robot motion starting point or in the first frame. Place the posture in the 3D motion window as basic posture Click first frame Insert the key frame at the top. Click on (Key icon)

Basic posture has been inserted in the key frame.

If the posture in the 3D motion window is not a basic posture, select it as basic posture from the tool bar on the right. (Shortcut Alt + I)






#### 03 3D Window

To enlarge the 3D window, Menu > View > Click on 'New 3D Window'. Click and drag to enlarge the new 3D window.

#### 04 Motion Edit


Click on the robot joint and thin yellow joint movement line will appear. Click and hold left mouse button on the line and drag.

Lift the left hand up left and the right hand up front.




#### 05 Insert Edited Motion

Insert the motion edited in 3D window into desired timeframe. After inserting the motion, click on the " in at the top to view the simulation in the 3D window.



#### 06 Inserted Frame Midpoint Check

To view the motion between two frames, click on the timeframe section between the basic motion and the edited motion.



#### 07 Connecting to Robot

Use the USB to Serial converter cable to connect the robot to the USB port of PC or notebook computer. Click "Connect" icon to make the connection. Check the Com port if the connection does not occur. Click "Torque On" button and try moving the robot arm or the leg by hand. Torque is on if the robot does not move. Click on "Robot Play" button and robot will move following the created motion, This ends the first lesson on creating robot motion and play.

#### 08 Reference : COM Port Setting

If the connection to the robot does not occur, it is most likely due to wrong Com port settings.

Right click on "My Computer", click on "Properties" to open "System Properties" window, click on "Hardware" tab to open the device manager.


Click Com port to view the list of configurable Com ports. Select COM2 connected to the USB and save. Com port connected to the robot should now be open.

💠 Setting				×
	Setting			
			Move	
ver.1 • Rob pt Type			Арру	
• Seri al Port	2		Асру	
POLT Baudrate 20M12 V 115200 V	Stopbit 1	Parity None	Flowctri None	
• DRC ID Setting 253			Арру	

#### 09 Reference : COM Port Setting

Select COM2 and save. Robot and PC software should now connect.


# User Interface



- Instructions : DR-SIM detailed user instructions. Press F1 to view Help .
- **Short Cut :** Collection of frequently used menus. Simulation Play, Insert Keyframe, and etc.
- **2** Mini Timeline : Shows the outline of whole timeframe.
- **3 Timeline** : Created or edited motion can be placed by time.
- **3D Motion Window :** Edit robot motion or view the motion simulation.
- **5** Face LED : Enables user to edit Face LED. Insert into timeframe after editing.
- **Sound :** Select saved sound. Insert into timeframe after selection.
- **Motor Setup Window :** Configure values and LED settings by ID for all motors used in the robot.
- 8 Connect Robot : Shortcut for connecting to the robot. Used to download motion file to the robot or to capture actual robot motion.



Click 'Help' on the menu bar to popup the help window. We recommend reading the Help files prior to using the DR-SIMprogram. (Click 'Help' > Click'Index' > Click 'Timeline' on left menu → Window shown below will open up



- **Com Setting :** Instruction on setting up the COM port.
- Main Window Major Functions : Instructions on how to use program functions.
  - Menu Bar Quick Menu Robot Control Setting Timeline 3D Motion Window Face LED Servo Motor Values Environment Setting

#### Tutorial

Creating Simple Motion : Explanation about sample motion creation.

Check our website for more motion samples.

# Download

Edited motions are saved as a file. Saved motions files can be batch downloaded to the DRC controller (Existing files in the DRC will be deleted). Downloaded files are ginve a number according to the order of download which then can be loaded and used by DR-Visual Logic(Task Editor).

🗀 motionhello		*	6 💋	Þ	•	
🖬 capture, dmt 🖬 hello, lmt						
🗟 pushup, dmt						
🗟 sitdovrn, dmt						
1 Click						
						2 Click)
	capture, dmt			•	~	sav <u>e</u>
	Motion File(*,dmt)			•	~	취소

#### Save Robot Motion

To save the robot motion, File  $\rangle$  Save As  $\rangle$  insert file name and save.





#### 01 Robot Control

With the robot and DR-SIM connected, click on "Robot Control" icon.

#### 02 Robot Control Window

Motion information download popup opens up. Top section shows the directoy of saved motion files, Left window shows motion list saved in the PC. Files downloaded to the DRC will be listed by number on the right window.



#### 03 Open Saved File Folder

Click on the folder icon at the right side of the folder directory to open up the folder search popup window. Click to select the folder where the motion files are saved.



Load Execute

#### 04 Motion List

Left window shows the list of motions in the selected folder. Place the cursor on the list and click the download icon.

#### [Reference]

🧇 Robot Control

capturetur pushup.dmt sitdown.dmt

Motion Download

Motion list folder

- Motion data is loaded automatically from the selected folder
   When 'Download' button is clicked, motion data in the controller is rewritten based on the data in the motion editor,
- 'Load' button loads the current motion data in the controller
   When 'Start' button is clicked, robot will execute the selected motion data through the controller,
   Robot may restart itself automatically during the data transmission between the motion editor and the controller,

Click

Clic



#### 05 Download


Robot motions will be downloaded one at a time.

Controller motion list
0. capture.dmt 1. hello.dmt 2. pushup.dmt 3. sitdown.dmt
Load Execute

#### 06 Controller Motion List

Once all the motions are downloaded, motions will be listed from number 0 in the controller motion list window on the right side.

Numbers can be called up by index when programming with DR–Visual Logic (Task Editor). This ends the lesson in robot motion download.




#### Creating Motion - Step by Step

There are two different methods of creating motion. One method is to use the 3D motion window, motion can be created by clicking on robot joints and using the motion lines. Another way is to capture the motion from the robot. Following lesson will show how to create motion by using both methods.

Section Editor	or - captu	ıre.،	
File View	Frame	Po	
New File	Ctrl+N		Click
Open	Ctrl+0		
Save	Ctrl+S		
Save As	F12		
Add Motion File	Ctrl+M		
Insert Motion	Ctrl+U		
Quit	Ctrl+Q		


#### 01 New File

File > Click on 'New File'.



#### 02 New Motion Window

Previous motion window will disappear and new robot 3D motion window will open.



#### 03 First Frame


Insert teh basic posture into the first frame. Click on the first frame and then click on the key frame insert.

#### 04 New Motion Window

Motion window can be opened up separtely and enlarged to conveniently edit motion on screen.

Total of three 3D motion windows can be opened at same time and placed side by side or top and bottom to be used for editing.

View > Click on 'New 3D Motion Window'. Use the mouse to drag and elarge the newly opened 3D popup window.



#### 05 Enlarging Robot

Robot in the edit window can be enlarged.

Click on an empty space and use the mouse wheel to zoome in or out, To change the angle, press and hold the right mouse button and drag.

To change the robot position, press shift + press and hold right mouse button and drag.

iotion Editor

View Frame Pose Robot

F4

Mideo Windo

Open MP3 Window ✓ 3D Motion Window
 ✓ Face LED Window

Servo Window

Time Line 3x

Time Line 2x Time Line 1x

Tool Help

124

Torque

**h**th

<u>▲</u> ÷

Å Ĩ


0 0


₿.

Click 🔊 📀

File

3D Mo







#### 06 Edit Arm Motion

Lifting the arm. Click on the shoulder area and yellow motion line will appear. Click and drag along the motion line to lift the arm.

#### 07 Insert Key Frame

Insert the lifted arm motion into the frame. Click on the desired frame and then click on 'key' icon to insert the motion.

#### 08-1 USB to Serial Converter

Start connection to the robot. USB to Serial conversion cable that connects robot to the PC/Notebook USB port.





#### 08-2 USB port

Connection to the PCs with Serial Port in the back can made using the serial cable but connection to notebook computers without the serial port requires USB to Serial converter.



#### 08-3 Connecting to Robot

Connect the RS232c audio jack to the robot.



#### 08-4 Robot Port

Looking at top of the DRC controller, you will find serial port connecting to the PC, head side servo motor port, and power port.

Photo shows all three ports connected.

_				Click
Forque On	Off Pose	Capture	Motion P	lay { top
		Connect	Robot Control	Setting

#### 08-5 Robot Connection Button

Menu for making connection to the robot is located at top right of DR–SIM window. Click on 'Environment Setup' button to configure the COM Port.



• Robot Type				Apply
Hovis Lite 18 D		Click		Apply
Hovis Eco 16 DOF Hovis Eco 18 DOF	audrate	Stopbit	Parity	Flowctrl
CHOYIS ECO 20 DOF	200 🔽	1	None	None

° Seria	l Po	rt				Apply
PORT		Baudra	ite	Stopbit	Parity	Flowctri
COM12	~	115200	*	1	None	None
	י שו	etting	-0	lick		Apply





#### 09 Environment Setup

Environment Setup window shows DR-SIM version, robot selection, and Communications setting.

#### 10 Robot Selection

DR–SIM provides total of 6 different types of humanoid robot. Most basic robot is the 16 axis humanoid. Select the type of robot that was assembled. Select Hovis Lite 16 DOF

#### 11 COM Port Selection

"PORT" shows the COM Port numbers that can be selected. Select one of the ports. If there is no connection, go to the hardware properties in windows and check the number of the COM port that can be used.

#### 12 Connecting

Click on the 'Connect' icon.


#### 13 Connection

As shown in the left photo, Torque button becomes active when connection to the robot is made. Click "Torque On" button to operate the robot and click 'Play' button to play current motion.



#### 14 Robot Motion for Capture

This lesson will show how to caputre and edit motion from the robot.Click "Torque Off" button and then manually manipulate the robot to make desired motion.






#### 15-1 Capture

Click 'Capture' button.


#### 15-2 Show Captured Motion in 3D Window

Captured motion is shown in the 3D motion window as soon as capture button is clicked.



#### 15-3 Insert Key Frame

Insert captured motion into the desired frame. Click on the frame first and then click on the key frame.






#### 16-1 Different Motion

Manually make a different motion.






Capture.




#### 17 Check Motion

Compare the manually made motion with the motion in the 3D motion window.

Torque On Off	Pose Apply	Motion	lay (Stop)
	Click connect	Robot Control	Setting





#### 18 Capturing

Capture the newly made motion


#### 19 Insert Key Frame

Insert motion in the desired frame.

#### 20 Delay Value

Robot may make a suden movement if there is a large motion difference between the first and the second motion key frame. To prevent such a sudden movement, there is a way slow down the first motion.

Click bottom of the frame and drag to the right with left mouse button pressed. Such an action will show up as photo on the left and Delay value will be created.



	<b>B</b> 8	Ġ	6 /	e (A	Û	P a	ρ	•	00	)																			연결잖기
	*		•			•																							
( ) / *	15 B		a 20					*	~	9			*	55	ю	10			-	8	- 10	10	- 10			10	**		н
	•																												
																	1												
DEREDEEBER	REFE		Seconds.	vos kieros		den se de la	14 1 1 2		nodiji)	1 Hot	ci i i i	4.0000	ione -	or idea	مسمه	(intervi		C 9 2 7 4	- 51-30	e v u bivi	-10443		risen (c	nin or	nnste		1.00	statisty s	100100

#### 21 Screen Play

Play the created motion in the motion window.

Click 'Play' icon.

#### 22 Play

Progress line shows the motion being played progressing on the time frame.

Torque On Off	ose Capture Apply	Motion	Play Stop
	Disconnect	Robot Con	Click ing

#### 23 Play On Robot

Apply and play the motion on robot. Click 'Play' button located near top right.




#### 24 Robot Motion

Left photo shows the motion created in 3D motion window. middle and right photos show captured motions. When played, motions will be played consecutively.

# **Multimedia Effect**

#### Editing and applying face LED effect to robot motion

We will use DR-SIM to apply face LED effect to the robot motion. Face LED enables robot to simulate emotions during motion. Steps in creating and running facial LED effect consists of editing face LED effect according to each type of emotion, saving LED effect to PC, downloading to the robot, and applying effect from the motion frame to the robot motion.



#### O1 Face LED edit window

Click Face LED > Select/Edit button to open facel LED edit window.



#### 02 Edit face LED according to each type of emotion.

Edit face LED according to each type of emotion. In this example, we will edit face LED to express happiness.

(1) Click "happy" from the emotion list window on the left

(2) Select desired color from the color palette window and use mouse click to apply to the robot forehead, ears, nose, and eyes. (Color applied to eyes only).
(3) Save edited effect. (Save to PC).
(4) Try editing other emotions,



#### 03 Download face LED effect

Edited face LED effect must be downloaded to the robot in order to apply the effect to the motion.

Press download button to download the edited/saved LED data to the robot.

% Prior to downloading, check robot power status and robot to PC connection.

% It takes approximately 10s to download complete LED data to the robot.

DR-SIM - 15.box.dmt	_	_			_		□ ×
타일 보기 프레임 포즈	로봇 도구	도움말		토크 On 0	이 포즈(1	(적용) 로봇실행 (	Play Stop
	3 🖻 X 🕻	3028	• • • •	)		연결하기 로봇제어	환경설정
				1.	<b></b>	•	
118 120 128 131	0 135 140	145 150	155 160	188 170 175	180 185	190 195	200
575656566192838485868786897071727374	757677787980818283848	506070605000102030405	8070000 00 <mark>1</mark> 120.5	e 7 a 9101112101415ten7101900 8	2 2 4 5 8 7 2		12225
3D 모션 윈도우	Fran	ne : 156.000000	얼굴 LED	서보 모터값	-	_	-
3D 모션 윈도우	Fran		영굴 LED Index: 0	서보 모터값 LED Motor ID V4	alue LE	D   Motor ID   V	/alue
3D 모션 원도우	Fran	1e : 155.00000		LED Motor ID V	alue LE	▼ 003 LA. Up	/alue  -33 ^
30 모션 원도우	Fran	00		LED Motor ID V	0 7 G	<ul> <li>003 LA.Up</li> <li>004 LA.Wing</li> </ul>	-33 ^ 91
90 모션 원도우	Fran	0 0 0 0 0 0 0 0	Index : 0	LED Motor ID V	0 3	▼ 003 LA. Up	-33 *
30 모션 원도우	Fran	0 0 0 0	Index : 0	LED Motor ID V : . :	0 8 G 91 8 G 71 8 G	<ul> <li>003 LA. Up</li> <li>004: LA. Wing</li> <li>005: LA. Down</li> </ul>	-33 * 91 59
30 모션 원도우	Fran	0 0 0 0 0 0 0 0	Index : 0	LED Motor ID V :	0 6 91 6 71 6 0 7 6	× 003 LA. Up     × 004 LA. Wing     × 005 LA. Down     × 005 LA. Down     × 011:LL. Wing	-33 * 91 59 0
92 22 25 P	Fran	00 00 00 00 00 00 00 00 00 00 00 00 00	Index : 0	LED         Motor ID         V           Image: State of the state o	0 76 91 76 71 76 28 76 56 76 28 76	▼ 003 LA.Up           ▼ 003 LA.Up           ▼ 004:LA.Wing           ▼ 005 LA.Down           ▼ 001:LL.Wing           ▼ 012:LL.Tilt           ▼ 013:LL.Knee           ▼ 014:LF.Tilt	-33 × 91 59 0 28 59 29
30 II 4 B II 7	Fran		Index : 0 선택/판합 발신용	LED Motor ID V 	0 1 6 91 7 6 71 6 28 7 6	<ul> <li>V003LA.Up</li> <li>V003LA.Up</li> <li>V005LA.Down</li> <li>V005LA.Down</li> <li>V011LL.Wing</li> <li>V011LL.Wing</li> <li>V013LL.Knee</li> <li>V014LF.Tili</li> <li>V015LF.Wing</li> </ul>	-33 * 91 59 0 = 28 59 29 -3
30 24 <u>95</u>	Fran	00 00 00 00 00 00 00 00 00 00 00 00 00	index : 0 선택/편집	LED         Motor ID         V           Image: State	0 76 91 76 71 76 28 76 56 76 28 76	▼ 003 LA.Up           ▼ 003 LA.Up           ▼ 004:LA.Wing           ▼ 005 LA.Down           ▼ 001:LL.Wing           ▼ 012:LL.Tilt           ▼ 013:LL.Knee           ▼ 014:LF.Tilt	-33 × 91 59 0 28 59 29



#### O4 Applying to robot motion

Apply edited LED data to robot motion

(1) Select motion frame to apply LED effect.

(2) Click select/edit button from the face LED window.

(3) Select effect from the list window on the left and then click select button below.

(4) Apply LED effect to other motion frames.